

DUAL RAIL SUSPENDED MOUNT STALL SYSTEM (6F00020)

Installation Manual 5MC60010



support@senecadairysystems.com
Phone: (315) 712-0118 Fax: (315) 712-0108



1. Lag or bolt the *Post Clamp for Dual Tube (part #3F01465)* to the 6"x6" wooden post. Then use the 1/2"x2"x5" square U-bolts (*included*) to fasten the rectangular tube to the *Post Clamp for Dual Tube*.




2. Use the 1/2"x2"x5" Square U-bolts (*included*) and the V tube Clamp (*part #3F01470*) to fasten the Vertical Suspension Tubes w/ TCM to the rectangle tube.



3. Slide the freestall loop into the TCM on the Vertical Suspension Tubes w/TCM and bolt them in place using the 7/16"x3-1/2" bolts.



NOTE: To figure the mounting height for the Post Clamp for Dual Tube you need to know how high you want your stalls. The chart and illustration below will help you with determining the height of the stalls for your specific herd and needs.



WEIGHT (lbs)	HEIGHT of "A"
300 - 400	30" - 33"
400 - 700	33" - 38"
700 - 900	38" - 42"
900 - 1100	42" - 44"
1100 - 1300	44" - 48"
1300 - 1700	48" - 51"
1700 +	53"